CS-200



4-Slot Mobile POS Terminal Charger User Manual

The CS-200 4-slot battery charger is an accessory serving for the MT mobile POS terminal. The charger can charge up to 4 units of MT terminals each time.

Important Instructions:

Please read this manual before you use the charger, and save it for reference.

Caution:

- ♦ Do not disassemble the charger.
- ♦ Do not use the charger as a power source for any electrical equipment.
- ♦ Use the charger in a well ventilated area and keeps it away from electrically conductive or inflammable materials.
- ♦ Keep the charger well away from areas of dust, damp, rain, heat, direct sunshine and vibration and do not make it drop.
- ♦ Do not plug the charger into any extension power socket.
- ♦ Always unplug the charger from outlet before maintaining or cleaning the charger.

Package Contents:

- ♦ CS-200 4-slot mobile POS terminal charger (x 1)
- ♦ 12V/60W Power adaptor + power cord (x 1) (depending on country type ordered)


Features:

- ♦ 4- slot battery charger
- ♦ Automatic detection of battery capacity
- ♦ User-friendly
- ♦ Clear indication of the charging state of each slot

View of the CS-200:

➤ Top View of CS-200:

Bottom View of CS-200:




Battery charging status LED for each system

Charging the battery:

1. Connect the connector of power adapter to the "DC IN" power jack on the bottom of the charger. Plug the AC power adapter cord into AC outlet.



- 2. Plug the power adapter into an outlet.
- 3. Insert one or more MT-series terminals firmly into the charger slot in orientation.



- 4. The charger will automatically detect the capacity of each battery and begin charging. The LED indicator on the charger turns orange blink.
- 5. When the MT-series terminal is fully charged, the LED indicator on the charger turns solid green.
- 6. In stand-by mode, it takes just about 5 hours for the charger to fully charge a battery; in power-off mode, it takes just about 4 hours.

NOTE: CS-200 can also charge the MT-series terminal even if the MT-series terminal is powered ON. However, for safety concern, we recommend that you power off the MT-series terminal before charging.

LED Indicator Status:

- ♦ Orange: Charger power ON
- ♦ Orange blink every 0.5 second: battery capacity under 80%
- ♦ Green blink every 1 second: battery capacity above 80%
- ♦ Green: charge full

Specifications:

Power Input	12V DC/60W
Power Output	5V DC/ 2A (Max.) per slot
Number of Charger Slot	4 slots (Max.)
Operating Condition	5°C ~ 40°C, 20% RH ~ 90% RH
Storage Condition	-20°C - 45°C, 10%RH - 90%RH